ARA Quick Start Guide

**Below you will find information on how to get started with your ARA instrument.**

Please read and understand the ARA User Manual prior to operation. Failure to understand the ARA User Manual may result in serious injury or death.

Note: The information below is not a substitute for the ARA User Manual.

Activating ARA

Press down and hold the button for approximately 5 seconds. ARA will then go through the self-test sequence which is as follows: audible alarm, flash and vibrate.

You will see the following displays on the ARA device in sequence:

	All icons will appear
	Low alarm
	High alarm
	Home screen display: Lifetime remaining

Pioneering Gas Sensing Technology.
ionscience.com

NEED HELP?

SCAN OR CLICK HERE TO CONTACT US

airmet
Air-Met Scientific
www.airmet.com.au

Alarms and Messages

Below shows the symbols that may appear on your ARA device and a description of what they mean.

Mode	Symbol	Description
Alarm	**ALARM**	HIGH/LOW Alarms
	LOW	LOW Alarms
	HIGH	HIGH Alarms
Sensor	H_2S	H_2S sensor (blinking: Self-Test required)
	CO	CO sensor (blinking: Self-Test required)
	O_2	O_2 sensor (blinking: Self-Test required)
	SO_2	SO_2 sensor (blinking: Self-Test required)
Warning	⚠	Self-Test, Bump-Test, Calibration failed
	max	Exposed to gas above Low alarm set points
	▢▧	blinking: Bump-Test required
Unit	%	to display unit of O_2 sensor
	ppm	to display unit of H_2S/CO/SO_2
Time	⏱	to display Life Remaining
	months	to display time over 1 month
	days	to display time over 24 hours

Note: For more information, please refer to the ARA User Manual.